

# Assembly Instruction Sheet #IS-1090W21-3-620


## For Style 1090W21-3-620

**Tools Required:** Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.  
**Light Source:** (3) 120V LED, 30W DIMMABLE (3000K).  
**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

### ⚠ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.


### Package Contents




### Hardware Contents

PART	DESCRIPTION	QUANTITY
AA	Wire nut	3pcs
BB	Outlet Box Screw	4pcs
CC	Mounting Screw	4pcs
DD	Mounting bracket	1pcs


### STEP 1 – Attach Mounting Screws, Lock Washers and Hex Nuts to Mounting bracket



### STEP 2 – Attach Mounting bracket to Outlet Box




### STEP 3 – Wire Connections



### STEP 4 – Install Backplate to Ceiling

A. Place Backplate over the Mounting bracket (DD). Line up the hole on the Backplate and the mounting hole on the Mounting bracket, secure by threading Mounting Screw (CC) into the Mounting bracket (DD), tighten until snug.



### STEP 5 – Install Glass

A. Put the Glass (B) on the Fixture Body slot.

